

RDI


Range Data, Inc.

SCADA

Lift Stations

Water Towers

Your Cellular Alarm Monitoring Experts



TankVitals.com

Lifetime Warranty

Proudly Made in the USA

RDI

Range Data, Inc.

Congratulations on your new S2C device.

Proudly Made in USA by Veterans!

*Welcome to the **RDI** family!*

RDI's S2C is a mini SCADA (supervisory control and data acquisition) software that monitors your industrial processes and gathers data in real-time. This S2C reports all data alarms to you in Text/Email Messages and you can also print out the history reports in Excel or PDF reports.

S2C communicates with Wonderware SCADA.

RDI's S2C monitors up to 4 pumps and its selectable for the # of pumps you have!

Requires 120Vac
Up to 12 Input Ports *each timer removes 1 Input port
Up to 4 Run Timers Selectable
1 Relay to Control
Bluetooth Communication Connection
Operating temperature range is -40°F to 149°F (-40°C to 65°C)

Specifications

Power

UL approved AC Line Power Supply is a Regulated Converter

- Wide input range 85-305Vac
- Operating Temperature Range: -40°C to +85°C (-40°F to 185°F)
- Ultra-high efficiency over entire load range
- No external components necessary
- International EMC compliant
- 140% Peak load capability

Dimensions

- Size / Dimension: 4.183" L x 3.551" W (106.25mm x 90.20mm)
- Height: 3.540" (89.92mm)
- Design: Plastic, ABS/PC Blend
- Color: Gray
- Weight :1.11 lb (503.49g)

Temperature Sensor

- Measures Temperatures from -40°C to +85°C (-40°F to 185°F)
- ±0.5°C Accuracy from -10°C to +85°C

Cellular

- USA: Verizon Wireless,
- Canada: All Wireless systems
- Includes VPN (virtual private network) Protection
- Contains FCC ID:RI7CE910-DUAL This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interferences, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Inputs

- Alarm Inputs 1-12 and Pump 1-2-3-4 Run Timers are 120Vac optically isolated inputs.


Note: Inputs completes a path to Neutral

- Circuits for safe protective separation against electrical shock according to safety class II (reinforced isolation): - for appl. Class I to IV at mains voltage ≤ 300 V - for appl. Class I to III at mains voltage ≤ 600 V

S2C 12-Inputs Alarm and Four Inputs of 4-20mA

4 Channels, Isolated Two-wire Operation, Power is obtained directly from the 4 to 20 mA loop (input impedance 10 ohms), with no need for separate power input.

Requires 120Vac
Input 4-20mA 4 Channels
Up to 12 Input Ports *each timer removes 1-Input port
Up to 4 Run Timers Selectable
1 Relay to Control
Bluetooth Communication Connection
Temperature Sensor -40°F to 149°F (-40°C to 65°C)



Models of S2C 4-20mA Model

S2C 4-20mA 4Channel Input Models: *(With or with out the Enclosure)*

1. (S2C-Din) Rail Mount. (No enclosure)
2. (S2C-4x) with Enclosure.

LED Display and Select Button Operation

- 1 button push gives the mA value of input 1 (Will display for 10 minutes)
- 2 button push gives the mA value of input 2 (Will display for 10 minutes)
- 3 button push gives the mA value of input 3 (Will display for 10 minutes)
- 4 button push gives the mA value of input 4 (Will display for 10 minutes)
- 5 button push gives the RSSI Value
- 6 button push gives the Real Time Clock in military time
- 7 button push gives the Temperature
- 8 button push gives Code Version

LED Display and Cmd Button Operation

- 1 Button Push Sends Data to Website(if modem is not registered it will display all zeros)
- 2 Reset
- 3 Relay ON
- 4 Relay OFF
- 5 Test LED Bar Lights
- 6 Get SIM number
- 7 IP Address
- 8 Status of Inputs 1-4 where 0 = pump run timer 1>= alarm input
- 9 Activate SIM (after 9 button presses unit will start counting down to zero, press Cmd key one time before zero count to enable SIM)"
- 10 Reset Blue Tooth Module
- 11 Program Name into Blue Tooth Module
- 12 De-Activate SIM (after 9 button presses, unit will start counting down to zero, press Cmd key one time before zero)
- 13 Program for MySiteVitals.com
- 14 Program for TankVitals.com

LED Display

- Ⓐ Acknowledgement
- Ⓕ No Acknowledgement from Server
- Ⓕ Modem Failure
- Ⓕ Antenna Failure
- Ⓖ Received Message from Server
- Ⓕ- AC Power Failed (Will flash and all LED are lit)



Power Up sequence

First 60 seconds it may display

Select Window: 1 2 3 4 5 6 7 8

Then Three LED Windows

Left LED: 0 1 2 3 4 5 6 7 8

Centrer LED: 0 1 2 3 4 5 6 7 8

Right LED: 0 1 2 3 4 5 6 7 8

Then the RED Alarm Input Bar will sequence from left to right.

Right LED: 9 8 7 6 5 4 3 2 1

Right LED: 0 1 2 3 4 5 6 7 8

Centrer LED: Ⓕ (Checking Antenna Connection)

If Ⓕ Flashes means no Antenna is connected or is damaged.

Centrer LED: -

Then from left to right it will sequence the - for 6 times

Then form left to right it will display 1 2 3 (Sending data to server)

If all is working it will display Ⓐ (Acknowledgement sever received data) else it will display Ⓕ ***No Acknowledgement from Server (then call us)***

Optional Components



Tamper Proof Cellular Antenna
Mounts to Metal Enclosure



Selectable Current Sensors 30,
60 or 100 Amp




24Vdc Power Supply
AC/DC DIN RAIL
SUPPLY 24V 10W




External Dimensions 12.60 x 10.60 x 5.22 in
Polycarbonate
NEMA Rating 1, 2, 3, 3R, 3RX, 3S, 3SX, 3X, 4, 4X, 5, 12, 13
Weight 4.95 lbs
Gasketed enclosure, latch, 4 mounting screws, and 4 cover
screw hole plugs
Flame Rating UL94 5VA
UL & cUL File Number E352997

Power Connection



No Cellular Signal

If for some reason the Cellular signal is lost due to service provider or antenna problem you can select the option in Modem setup to RSSI Watchdog and this will activate the relay if cellular signal is lost.





Display showing F9 Antenna Failure

Input Connections

Alarm and Pump Input accept the Hot Line wire from each of your devices.

Note*: If your device is a relay contact then supply the other half with the AC Line (Hot) to complete the circuit.





Typical Input connection to Input 12
If your test lamp lights up then our input 12 LED will also light up.




Input 1 connect to Pump 1 Motor Contactor or L1 of motor phase wire
Input 2 connect to Pump 2 Motor Contactor or L1 of motor phase wire
Input 3 connect to Pump 3 Motor Contactor or L1 of motor phase wire
Input 4 connect to Pump 4 Motor Contactor or L1 of motor phase wire

Input 5 to 12 Can be connected to other alarm monitoring points.
i.e. High Water Float, Low Water Float, Red Light/Horn, Pump Seal fails,
Pump Overload Fail.


Input Connections



Pump Run Timer Input Connections




UPS Backup Connections



Select Input 5 to N.C. to invert the Power Fail alarm in the Software Input Module setup.
When Power fails an alarm is sent via Your selection (Phone, Text, Email)

4-20mA Connections to Monitor a Device



Change/Add Users



The screenshot shows the 'Administration' section of the TankVitals website. It features a table with columns for Email, Contact Name, Address, City, State, Postal Code, Phone Number, Text Number, Email Msg, and Voice Msg. Two users are listed: Jack Mitchell and Mike Mitchell.


	Email	Contact Name	Address	City	State	Postal Code	Phone Number	Text Number	Email Msg	Voice Msg
View	jack@rangedata.net	Jack Mitchell	114 Eastwood Dr	Grafton	ND	58237	7013314065	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
View	mike@rangedata.net	Mike Mitchell	1382 T666th St	Tower	MN	55790	2184104043	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>

TankVitals

Hello jack@rangedata.net! [Logout](#)

Register

Create a new account.



The registration form consists of the following fields:

- Contact Name
- Address
- City
- State
- PostalCode
- PhoneNumber
- Email
- Password
- Confirm password
- Viewer

A blue 'Register' button is located at the bottom of the form.

© 2025 - TankVitals

When entering the Phone number do not use dashes (-) just the number, for the zip code use the 5 digits .

Use View for users to view the information and Manager for those that need to make changes to the site.

FYI: This information is never shared or released to anyone.

Change/Add Users

Edit User windows is used to modify the user information.

Here you can turn on or off the messages to be sent.

Edit User ✕

Email	<input type="text" value="jack@rangedata.net"/>		
Contact Name	<input type="text" value="Jack Mihelich"/>		
Phone Number	<input type="text" value="7013314085"/>	Password	<input type="text" value="*****"/>
Address	<input type="text" value="114 Eastwood Dr"/>		
City	<input type="text" value="Grafton"/>	State	<input type="text" value="ND"/>
Postal Code	<input type="text" value="58237"/>	Role	<input type="text"/>

Send Email Msg

Send Text Msg

Send Voice Msg

Edit Parameters Tab

DUAL9 Jack Office

Pump Run Reports History

AcPower: **On**
Temperature 76.1°F

Last Tx Time: **Aug 26, 2024 11:26:09 PM *** Error *****

Pump Timers
Pump1: 508.99 Hrs.
Pump2: 68.83 Hrs.

All Alarm Notifications are: **ENABLED**

Input-Alarm Status: **No Alarms**



- Edit Parameters
- Button Push

Select Edit Parameters to setup the S2C for your site operation.

S2C BlueTooth 1

History Edit Parameters Button Push

AcPower: **On**
Temperature Probe is Missing

Last Tx Time: Aug 29, 2024 12:48:55 PM


Pump Timers
Pump1: 21.90 Hrs.
Pump2: 0.65 Hrs.

All Alarm Notifications are: **DISABLED**

P2 Run Timer

Input-Alarm Status: **A L A R M**

4-20mA Connections for Current Sensor Install



Press the Select button 1 push this gives the mA value of Input 1 (Will display for 10 minutes)

Sites Main Page

TankVitals Hello_info@rangedata.net | Log out | About

Sites

Change/AddUser

Q&A

Show Demo

New feature: To monitor pump 1 & 2 for zero-time usage. Select Edit Parameters, under Input Module select Pumps Setup, select edit then enable Monitor Pump for zero time. This will only send an email.

Lift Station To The North

Pump Run Reports History

AcPower: On
Temperature 74.5°F

Temperature Reports

Last Tx Time: Feb 13, 2024 12:01:54 PM *** Error ***

All Alarm Notifications are: ENABLED
Input-Alarm Status: No Alarms

Lift Station Down The Road

Pump Run Reports History Edit Parameters


AcPower: Off
Temperature 69.0°F

Last Tx Time: Mar 28, 2024 12:30:42 PM *** Error ***

Pump Timers
Pump1: 0.95 Hrs.
Pump2: 0.34 Hrs.

All Alarm Notifications are: ENABLED
AC POWER OFF
Input-Alarm Status: **ALARM**

Lift Station Down The Road



Level Value: 0.00

H-Alarm: 80.00
0.00 Feet
or 0.00mA
L-Alarm: 20

Update Data

Level +
mA-Alarm Status: **ALARM**

Module Operation Main Screen

The Main Parameter Screen where you can adjust the behaviour of the S2C device.

The three main parts are

Modem, **Input**, and the **4-20mA** modules.

Lift Station Down The Road

Modem Module

Alarm: Disabled, Delay & Tx Time Relay Description Temperature Alarm Module Info

	Site Name	Disable ALL ALARMS	Disable Inputs Tx	Daily Tx Time	Number of Updates per Day
Edit	Lift Station Down The Road	Enabled	Enabled	1/1/0001 12:00:00 AM	12 Hr or 2 Tx/Day

Setting "Disable Inputs Tx" to Disable will turn off Cellular transmissions.

[Send Modem Parameters](#)

Input Module

Alarms Description Enable/Disable Alarms Alarm Delay Times Input N.O. / N.C. Pumps Setup Pump 1 Timers Pump 2 Timers Info

	Run Timer1	Run Timer2	Input 3	Input 4	Input 5	Input 6	Input 7	Input 8	Input 9	Input 10	Input 11	Input 12
Edit	P1 Run Time	P2 Run Time	Hi Float	NAA4	NAA5	NAA6	NAA7	NAA8	NAA9	NAA10	NAA11	NAA12

[Send Input Parameters](#)

4-20 Miliamp Module

Relay Description & Module# Enable/Disable Alarms Well Pump Setup Input 1 Setup Input 2 Setup Input 3 Setup Input 4 Setup Module Info

	Module Address	OneWire 4-20mA PIN
Edit	0	0

[Send 4-20mA Parameters](#)

Modem Module Operation

Modem Module

Alarm: Disabled, Delay & Tx Time. Relay Description Temperature Alarm Module Info

	Site Name	Disable ALLALARMS	Disable Inputs Tx	Daily Tx Time	Alarm Delay in Sec.	Number of Updates per Day
Edit	Tower Lakes Lift Station	Enabled	Enabled	1/1/0001 12:00:00 AM	5	12 Hr or 2 Tx/Day

Setting "Disable Inputs Tx" to Disable will turn off Cellular transmissions.

The Alarm Delay is used to make sure the alarm is true and not chatter. This is a global setting applied to all alarm inputs. Range is 2sec. to 99sec.

There is nothing to gain by increasing the number of times the S2C transmit the data to the Web site. 12 Hr or 2Tx/Day is the best choice.

The system checks to see if the S2C has sent the last two transmissions have been sent, if not then and alarm email / text will be sent.

[Send Modem Parameters](#)

Disable all alarms will stop all alarms to be sent out. Use this when unit is being serviced. Disable Inputs will prevent Alarm Inputs 1-12 to stop sending out alarms.

Modem Module

Alarm: Disabled, Delay & Tx Time. Relay Description Temperature Alarm Module Info

	Relay	Relay	RSSI WatchDog
Edit	NA.Relay1	NA.Relay2	False

Enter NA to Disable the relay

[Send Modem Parameters](#)

RSSI Watchdog will close the relay if cellular signal is lost

Modem Module

Alarm: Disabled, Delay & Tx Time. Relay Description Temperature Alarm Module Info

	High Temp Alarm Set Point	Low Temp Alarm Set Point	Hysteresis for Temperature in Deg's
Edit	130	-5	1

The S2C operates within -40°F to 145°F. Anything above or below that range the S2C stops. It will start working automatically if the S2C is within the operating range.

Your Hysteresis is set at 1°F and your High Temp Alarm is set at 130°F. The High temperature Alarm will be sent to you at 131°F and a High temperature Reset Alarm will be sent at 129°F.

The Below temperature Alarm will be sent to you at -6°F and a Low temperature Alarm Reset will be sent at -4°F.

When the hysteresis is too small, the output will chatter or send you a lot of alarms.

[Send Modem Parameters](#)

Modem Module

Alarm: Disabled, Delay & Tx Time. Relay Description Temperature Alarm Module Info

Inputs Tx	Probe Count	DeviceId	Cellular Signal	Code Ver
Disabled	0	164	0	0

Cellular Signal Range 0-45, Higher the number the better, if below 3 you will need to add a directional antenna.

[Send Modem Parameters](#)

Input Module Operation

Input Module

Alarms Description [Enable/Disable Alarms](#) [Input N.O. / N.C.](#) [Pumps Setup](#) [Pump 1 Timers](#) [Pump 2 Timers](#) [Info](#)

	Run Timer1	Run Timer2	Input 3	Input 4	Input 5	Input 6	Input 7	Input 8	Input 9	Input 10	Input 11	Input 12
Edit	P1 Run Timer	P2 Run Timer	P1 Failed	P2 Failed	P1 Seal Fail	P1 Seal Fail	High Water	Low Water	Red Light	P1 O/L Fail	P2 O/L Fail	NAA12

[Send Input Parameters](#)

Set up your naming of the Inputs assigned to the S2C

Input Module

Alarms Description [Enable/Disable Alarms](#) [Input N.O. / N.C.](#) [Pumps Setup](#) [Pump 1 Timers](#) [Pump 2 Timers](#) [Info](#)

	P1 RunTi...	P2 RunTi...	Input 3	Input 4	Input 5	Input 6	Input 7	Input 8	Input 9	Input 10	Input 11	Input 12
Edit	P1 RunTimer	P2 RunTimer	Enabled	Enabled	Disabled							

[Send Input Parameters](#)

If the input is over active or problem with the assigned alarm device you can prevent the alarm being sent out unit you have time to resolve the issues.

Input Module

Alarms Description [Enable/Disable Alarms](#) [Alarm Delay Times](#) [Input N.O. / N.C.](#) [Pumps Setup](#) [Pump 1 Timers](#) [Pump 2 Timers](#) [Info](#)

	P1 RunTime	P2 RunTime	Alarm 3	Alarm 4	Alarm 5	Alarm 6	Alarm 7	Alarm 8	Alarm 9	Alarm 10	Alarm 11	Alarm 12
Edit	0	0	2	2	2	2	2	2	2	2	2	2

Set Delay time in seconds (Default is 2 sec) for chatty float increase time to true float on condition. [Values: 1 sec to 99 sec] A zero "0" in the Alarm# will DISABLE the alarm. A zero in the Pump Run Time means Pump Timer

[Send Input Parameters](#)

Zero (0) is used for pump run timers. One (1) or greater is used for delay time in seconds before sending out an alarm. 2 seconds is the default. If you have a chatty float set the time until the float has a true alarm.

Input Module

Alarms Description [Enable/Disable Alarms](#) [Input N.O. / N.C.](#) [Pumps Setup](#) [Pump 1 Timers](#) [Pump 2 Timers](#) [Info](#)

	Input 1	Input 2	Input 3	Input 4	Input 5	Input 6	Input 7	Input 8	Input 9	Input 10	Input 11	Input 12
Edit	Normally Open	Normally Closed										

[Send Input Parameters](#)

Match your device operation if the relay is Normally Open (N.O.) or Normally Closed (N.C.)

Input Module Operation

Input Module

Alarms Description Enable/Disable Alarms Input N.O. / N.C. Pumps Setup Pump 1 Timers Pump 2 Timers Info

	Monitor Pump for zero time	Pump 1 Installed	Pump 2 Installed	Pump 3 Installed	Pump 4 Installed
P1 >	Disabled	Installed	Installed	Not Installed	Not Installed

Send Input Parameters

Monitor Pump for zero time is used to watch for sequencing error. If pump 1 or pump 2 has no run time for the day an email is sent out. "Pump # reported zero hours usage"

Input Module

Alarms Description Enable/Disable Alarms Input N.O. / N.C. Pumps Setup Pump 1 Timers Pump 2 Timers Info

	P-1 Meter Hours	P1 Today's Hrs	P1 GPMcal
P1 >	0.00	0.00	0.00

Send Input Parameters

Input Module

Alarms Description Enable/Disable Alarms Input N.O. / N.C. Pumps Setup Pump 1 Timers Pump 2 Timers Info

	P-2 Meter Hours	P2 Today's Hrs	P2 GPMcal
P2 >	0.00	0.00	0.00

Send Input Parameters

Adjust the meter hours to match what on the sites hour meters. If know the pipe output calibration.

You can also enter the GPMcal for monthly reports if you enter the P# GPMcal value

4-20mA Module Operation

4-20 Miliamp Module

Relay Description & Module# Enable/Disable Alarms Well Pump Setup Input 1 Setup Input 2 Setup Input 3 Setup Input 4 Setup Module Info

	Input 1	Input 2	Input 3	Input 4
⚙ Edit	False	False	False	False

Send 4-20mA Parameters

Enable or disable inputs alarms when trouble shouting problems.

4-20 Miliamp Module

Relay Description & Module# Enable/Disable Alarms Well Pump Setup Input 1 Setup Input 2 Setup Input 3 Setup Input 4 Setup Module Info

	High Water ...	Pump Off L...	Pump On L...	Low Water ...	Secondary ...	Water Level...	Chemical D...	Max mA Value	Min mA Value	Well Pump	Pump Contr...	mA Convers...
⚙ Edit	0	0	0	0	0	0	0	0	0	False	False	0

Send 4-20mA Parameters

4-20 Miliamp Module

Relay Description & Module# Enable/Disable Alarms Well Pump Setup Input 1 Setup Input 2 Setup Input 3 Setup Input 4 Setup Module Info

	Active Input 1	Input 1 Description	Unit of Measur...	Alarm Delay Time	1.High Alarm	1.Low Alam	1.Hysteresis	1.Max Value	1.Zero Offset Value
⚙ Edit	True	Level	Feet	0	80	20	0	100	0

For [1# Zero Offset Value] Note: set 5.1 for ZeroPt value if using Current Monitor if using 50Amps Sensor or set 4.6 if using 20Amps Sensor

For [1# High Alarm] if the High alarm value is greater then the Max value then no alarm is set

For [Unit of Measurement] Use (On/Off) for 4-20mA bool setting (a data type in computer science that represents two possible values, true or false) and set [Alarm Delay Time]

For [Unit of Measurement] Use (A) (cap) for current sensors

For [Input # Description] Use (NA) to disable the input.

Send 4-20mA Parameters

If the optional current sensor is used an offset value is needed for liner correction. Enter 5.2 for 50Amp or 4.6 for 20Amp sensors.

If the High alarm values is greater the Max value then no alarm is set.

For Unit of Measurement enter On/Off for bool setting and set alarm delay time to 1or greater.

For current sensors use letter A (cap) in the description.

Use NA to disable the input.

4-20mA Module Operation Modes

Send Input Parameters

4-20 Milliamps Module

Input 1 Setup Input 2 Setup Input 3 Setup Input 4 Setup Enable/Disable Pump Setup

Active Input 1	Input 1 Description	1 High Alarm	1 Low Alarm	1 Hysteresis	1 Max Value	1 Zero Offset Value	1 Alarm Delay	Total Gallons
<input checked="" type="checkbox"/>	Pond 1	70	-7	0	60	0	1	15778

Update Cancel

If High alarm values is greater than the MAX no alarm is set
Under Unit of Measurement the [On/Off] is letting the m-amps measure zero. On/Off letter [A] for the 20mA and offset is 4.6 or for the 50mA Offset is 5.2. [Amps] is for Selectable CTD

Send 4-20mA Parameters

Click on the drop down arrow

The Drop Down Choices

- Description
- Amps
- Pressure
- #'s
- Feet
- PPM
- Float Level
- On/Off
- Flow1
- Flow2
- Flow3
- Flow4

4-20mA Module For Pressure

Setting Up *Pressure*:

Typical Water Tower setup

Max value is the current level reading in mA.

So if you have a level reading of 24.25 and a mA value at 11.9 then we can use this to set the Max Value

Given:

$$24.25 \times 16 = 388$$

$$11.9 - 4 = 7.9 \text{ mA}$$

$$388 / 7.9 = 49.11$$

49.11 is the Max. Value to enter into our system [1.Max Value].

4-20mA Module for Amps

(Where # is the input channel number)

Input#: Set to True or Checked marked. This will display the device on the web site.

Input#: Description: Give it the name you like to identify our pump or device name.

Unit of Measurement#: Select Amp.

#.High Alarm: Set this to the alarm when the current excess the maximum value.

#.Low Alarm: Set this to the alarm when the current is blow the minimum value.

#.Hysteresis: Level at zero.

#.Max Value: Set this to the switch value on the current sensor 30, 60 or 100.

#.Zero Offset Value: Level this at zero (0).

#. Alarm Delay: Set this from 2 seconds to 60 seconds for how ever long it takes to get a good alarm. Do not use 0 seconds (*this will disable the alarm*)

4-20mA Module for # (Pounds)

(Where # is the input channel number)

Input#: Set to True or Checked marked. This will display the device on the web site.

Input#: Description: Give it the name you like to identify our scale or device name.

Unit of Measurement#: Select #'s.

#.High Alarm: Set this to the alarm when the current excess the maximum value.

#.Low Alarm: Set this to the alarm when the current is blow the minimum value.

#.Hysteresis: Level at 5. This is a good starting point.

#.Max Value: Set this to the maximum value of your scale.

#.Zero Offset Value: Level this at zero (0).

#. Alarm Delay: Set this from 2 seconds to 999 seconds for how ever long it takes to get a good alarm. Do not use 0 seconds (*this will disable the alarm*)

4-20mA Module for # (On/Off)

(Where # is the input channel number)

Input#: Set to True or Checked marked. This will display the device on the web site.

Input#: Description: Telemetry Fail Alarm or Give it the name you like to identify the device name.

Unit of Measurement#: Select On/Off.

#.High Alarm: Set this value to 1.

#.Low Alarm: Set this value to 0.


#.Hysteresis: Level at 0.

#.Max Value: Set this value to 1.

#.Zero Offset value: set this to zero (0).

#. Alarm Delay: Set this from 90 seconds or however long it takes to get a good alarm. Do not use 0 seconds
(*this will disable the alarm*)

4-20mA Module Flow Rate



Total Gal is the current value since the Last Tx Time: located below the AcPower: and Temperature.

By default we automatically send up the data twice a day.

The last reading of the day is programmed in the Modem setup Daily Tx Time field.

4-20mA Module Flow Rate Setup

Send Input Parameters

4-20 Milliamps Module

Input 1 Setup Input 2 Setup Input 3 Setup Input 4 Setup Enable/Disable

Active Input 1	Input 1 Description	Unit of Measurement	1.High Alarm	1.Low Alarm	1.Hysteresis	1.Max Value	1.Zero Offset Value	1.Alarm Delay	Total Gallons
<input checked="" type="checkbox"/>	Pond 1	Flow1	70	-7	0	60	0	1	15776

If High alarm values is greater than the MAX no alarm is set
Under Unit of Measurement the [On/Off] is letting the m-amps measure zero Or Use letter [A] for the 20mA and offset is 4.6 or for the 50mA Offset is 5.2 [Amps] is for Selectable CTD

Send 4-20mA Parameters

Input 1 Setup

Set the [**1.Max Value**] to match your meter.

Active Input 1: Needs to be check marked to show up on web page.

Input 1 Description: Pond 1 (this can be set to your flow site name).

Unit of Measurement: Set to Flow1.

High Alarm is automatically set to 10 plus the 1.Max Value field.

Low Alarm is automatically set to -7.

Note: Alarms are not used for flow monitoring.

1.Zero Offset is automatically set to 0.



1.Alarm Delay is not used

Total Gallons can be changed to match the meter on site.

4-20mA Module Flow Rate Data

Click on Flow Reports Button

Select the month this will display the data.
Then select Plot Graph.



Pump Run Reports

Select Your Data Month

History Reports

2024

Quarterly Report September **August** July Quarterly Report June May April Quarterly Report March February January

2023

Quarterly Report December November October Quarterly Report September August July Quarterly Report June May April Quarterly Report March February January

2022

Quarterly Report December November October Quarterly Report September August July Quarterly Report June May April Quarterly Report March February January

2021

November October Quarterly Report September August July Quarterly Report June May April Quarterly Report March February January

2020

Quarterly Report December November October Quarterly Report September August July Quarterly Report June May April Quarterly Report March February January

2019

Quarterly Report December

Export to Excel Export All Pages Plot Graph

Date	Pump24h	P1MGO	Pump24h	P2MGO	DayTotal	MGOtotal
01-Thursday	1.33	0.03	1.37	0.04	2.70	0.06
02-Friday	1.20	0.03	1.24	0.03	2.44	0.06
03-Saturday	1.25	0.03	1.26	0.03	2.51	0.06
04-Sunday	1.48	0.03	1.53	0.04	3.02	0.07
05-Monday	1.19	0.02	1.10	0.03	2.38	0.06
06-Tuesday	1.29	0.03	1.30	0.03	2.59	0.06
07-Wednesday	1.21	0.03	1.26	0.03	2.47	0.06


You can export to excel

You can plot a graph

Pumps Run Times and Temperature and Reports

8/1/2024 History Reports for Location: Main Lift

Export to .jpg



Excel Report

	A	B	C	D	E	F	G
1	Date	Pump1Hr	P1MGD	Pump2Hr	P2MGD	DayTotal	MGDtotal
2	08/01/2024 12:32:25 AM	1.33	0.03	1.37	0.04	2.70	0.06
3	08/02/2024 12:32:15 AM	1.20	0.03	1.24	0.03	2.44	0.06
4	08/03/2024 12:32:02 AM	1.25	0.03	1.26	0.03	2.51	0.06
5	08/04/2024 12:31:42 AM	1.48	0.03	1.53	0.04	3.02	0.07
6	08/05/2024 12:31:28 AM	1.19	0.02	1.18	0.03	2.38	0.06
7	08/06/2024 12:31:09 AM	1.29	0.03	1.30	0.03	2.59	0.06
8	08/07/2024 12:30:51 AM	1.21	0.03	1.26	0.03	2.47	0.06
9	08/08/2024 12:30:31 AM	1.20	0.03	1.20	0.03	2.40	0.06
10	08/09/2024 12:30:11 AM	1.41	0.03	1.43	0.04	2.84	0.07
11	08/10/2024 12:29:53 AM	1.17	0.02	1.19	0.03	2.36	0.06
12	08/11/2024 12:29:31 AM	1.26	0.03	1.27	0.03	2.53	0.06
13	08/12/2024 12:29:15 AM	1.09	0.02	1.11	0.03	2.19	0.05
14	08/13/2024 12:29:05 AM	1.13	0.02	1.18	0.03	2.31	0.05
15	08/14/2024 12:28:54 AM	1.16	0.02	1.13	0.03	2.29	0.05
16	08/15/2024 12:28:43 AM	1.25	0.03	1.27	0.03	2.52	0.06
17	08/16/2024 12:28:31 AM	1.29	0.03	1.34	0.04	2.63	0.06
18	08/17/2024 12:28:30 AM	1.45	0.03	1.46	0.04	2.91	0.07
19	08/18/2024 12:28:26 AM	1.30	0.03	1.30	0.03	2.60	0.06
20	08/19/2024 12:28:16 AM	1.27	0.03	1.29	0.03	2.57	0.06
21	08/20/2024 12:28:03 AM	1.23	0.03	1.28	0.03	2.50	0.06
22	08/21/2024 12:27:40 AM	1.18	0.02	1.20	0.03	2.37	0.06
23	08/22/2024 12:27:29 AM	1.20	0.03	1.19	0.03	2.39	0.06
24	08/23/2024 12:27:14 AM	1.29	0.03	1.33	0.04	2.62	0.06
25	08/24/2024 12:27:03 AM	1.25	0.03	1.29	0.03	2.54	0.06
26	08/25/2024 12:26:58 AM	1.41	0.03	1.43	0.04	2.85	0.07
27	08/26/2024 12:26:55 AM	1.27	0.03	1.25	0.03	2.52	0.06
28	08/27/2024 12:26:51 AM	1.29	0.03	1.32	0.03	2.61	0.06
29	08/28/2024 12:26:45 AM	1.20	0.03	1.20	0.03	2.40	0.06
30	08/29/2024 12:26:28 AM	1.09	0.02	1.08	0.03	2.17	0.05
31	08/30/2024 12:26:14 AM	1.05	0.02	1.07	0.03	2.12	0.05
32	08/31/2024 12:26:00 AM	1.18	0.02	1.19	0.03	2.38	0.06
33		Sum: 38.57	Sum: 0.81	Sum: 39.15	Sum: 1.036	Sum: 77.72	Sum: 1.84

We need the designated person information .

Email and Cellular number.

Also need a shipping to address in case we need to ship repair equipment and the Yearly Billing Address

Purchase Order number: _____

Company Name: _____

Email Address: _____

Cell Phone #: _____ (i.e.. 701-352-4696)

Billing Address: _____ (Yearly Fee)

Shipping Address: _____

City: _____ State: _____

Zip Code: _____ - _____

Data Information for this S2C device SIM:

8914800000 _____ IP: 10.73.13 ____ . ____

FYI: This information is never shared or released to anyone. Thanks!

Send this information to service@rangedata.net

S2C Alarm Input Identification Model/Schematic

Alarm Input Channel

1: _____ or Pump 1 Run Timer

2: _____ or Pump 2 Run Timer

3: _____ or Pump 3 Run Timer

4: _____ or Pump 4 Run Timer

5: _____

6: _____

7: _____

8: _____

9: _____

10: _____

11: _____

12: _____

4-20mA-1: _____

4-20mA-2: _____

4-20mA-3: _____

4-20mA-4: _____

Your Cellular Alarm Monitoring Experts

Output Custom APIs Alarms to Wonderware (push method) SCADA system
Easy Installation
Includes VPN (Virtual Private Network)
Internally DIN mount or Externally NEAM-4x

*Simpler, Faster and Smarter
Cellular System for your Location*



*Lifetime Warranty
Proudly Made in the USA*